
Standard Motor with Quick Disconnect

Wiring Option

SINGLE MOTOR HARDWIRED TO JUNCTION BOX (Electrician Required)




For additional information please email HDHsupport@hunterdouglas.com or call 800.229.5300.



Mulitple Standard Motors with Quick Disconnect Controlled by One Switch

Wiring Option

MOTOR HARDWIRED TO JUNCTION BOX (Electrician Required)




For additional information please email HDHsupport@hunterdouglas.com or call 800.229.5300.



Dual Standard Motor with Quick Disconnect

Wiring Option

DUAL MOTOR HARDWIRED TO JUNCTION BOX (Electrician Required)



For additional information please email HDHsupport@hunterdouglas.com or call 800.229.5300.

