


# Shutters FR - Café Style

## Diagram

A Café Style shutter is a shutter configuration in which the panel or panels do not completely cover the entire height of the window opening. The frame may be ordered to the same height as the panel (in two or three sided frame configurations) or the frame may be ordered at a different height than the panel (four-sided configuration). In a four sided Café Style configuration, when ordering please note the frame's height and width and make a note of the panel height.


If ordering a three sided inverted frame in which the panel and frame are the same height, then order as an "IF" for inverted frame.

### P1-L (Shown Below)



For outside mount, panel height is the measurement from the bottom of the frame to the top of the panel.

### P1IF-L Inverted three sided frame (café style)



### P2IF-LR Inverted, three sided frame (café style)

